

Jaquith Industries Inc.

Syracuse, NY 600 East Brighton Ave. PO Box 780

315-478-5700 13205-0780

Fax: 315-478-5707

F Metal Forms

Form Installation Procedure

BMF Forms are easy to set up following these simple step by step procedures.

Line Up and Stake

First form

After the grade "line" has been set (for the back forms), stand the first form on the ground under the "line" and put a stake in each end stake pocket.

Line up the form with the "line" (don't worry about raising it yet) and drive the stakes.

Raise and Wedge

you're ready for the second form. Raise the form to the line, and tap the Giant Wedges to lock the stakes. Now

Second form Join, Line Up, and Stake

the stakes. loosely to the first, and put a stake in the pocket near the free end of the form. Hold the form under the line and drive Connect the end of the second form

4. Raise, Wedge, and Lock

Raise the form to the line, and lock it with the Giant Wedges. On O-K Forms, tap the clamp or slide to lock the forms together.


First section Set Division Plates

division plates to the form. On O-K each form is locked up) hook the When the back forms are in, (or after

between the ends of the forms. Curb, Gutter and Curb Face Forms, place the division plate proper division-plate slot. forms, hook the division plate into the On Super

Set Front Form

form, square up the form, and drive the stakes. Now. . . raise the forms up to the grade line, and lock it in place with the Giant Wedges. division plates into the opposite (front) Next. . . hook the other ends of the



7. Curb and Gutter with Division Plates

Set the curb and the gutter forms as shown in steps (1) through (6).

Mount the curb face forms on the division plates, and lock them in place. (Lock O-K Curb Face Forms to the division plates with banana-shaped taper keys, and lock their ends together by tapping the end slides. Lock Super Curb Face Forms through the division plates with the sliding dowels.



